



# Realtek Ameba 1 Firmware Image

---

This document introduces firmware image output and how to update image over the air.

## Table of Contents

1	Introduction .....	3
2	OTA overview .....	3
2.1	OTA operation flow.....	4
2.2	Boot process flow .....	5
2.3	Upgraded Partition .....	6
3	Implement OTA over Wi-Fi.....	7
3.1	OTA using local download server .....	7
3.1.1	Build OTA Application image .....	7
3.1.2	Local download server .....	10
4	OTA Signature.....	12

## 1 Introduction

Over-the-air programming (OTA) provides a methodology of updating device firmware remotely via TCP/IP network connection.


## 2 Firmware Image Output

After building project source files, there are 2 files will be generated automatically. The first is *ram\_all.bin* that is containing boot loader and application image. And the second is *ota.bin* that is application only image. Those two image can be found at  
*SDK\_folder/project/project\_name/EWARM-RELEASE/Debug/Exe.*

## 3 Firmware Update Over the Air

### 3.1 Overview


#### 3.1.1 OTA operation flow



Note: During the step of “Erase Upgraded (Older) Image2 region”, the signature is set to 0xffffffff, which is invalid signature.


Note: OTA updater will change signature of another region from “81958711” to “01958711” when writing signature. Firmware with signature “01958711” is previous version, and with “81958711” is latest updated version.

### 3.1.2 Boot process flow



Boot loader will select latest (signature == “81958711”) updated image2 and load it to SRAM.

### 3.1.3 Upgraded Partition



In most case, we suggest only updating Upgraded Image 2.

Default Image2 can be updated if set SWAP\_UPDATE in update.c. This behavior may damage another region data, please use this at your own risk.

NOTE: Signature “81958711” is mean latest updated version. “01958711” is previous version.  
Boot loader will load latest version by default.

## 3.2 Implement OTA over Wi-Fi

### 3.2.1 OTA using local download server

The example shows how device updates image from a local download server. The local download server send image to device based on network socket.

Make sure both device and PC are connecting to the same local network.

### 3.2.2 Build OTA Application image

#### Turn on OTA command

The flag defined in \project\realtek\_ameba1\_va0\_example\inc\platform\_opts.h

```
//Config in platform_opts.h  
#define CONFIG_OTA_UPDATE    1
```

**Define server type = SERVER\_LOCAL in update.c file (path: tools\DownloadServer\).**

```
//Config in update.c  
#define SERVER_LOCAL      1  
#define SERVER_CLOUD      2  
#define SERVER_TYPE       SERVER_LOCAL
```

**Define SWAP\_UPDATE in update.c file**

```
//Config in update.c  
#define SWAP_UPDATE 1
```

Enable this will update OTA image to Default (Part1) Image2 region. This behavior may damage another region data, please use this at your own risk.

## Write the address of the upgraded image 2 to system data.

Use the following sample code to write the upgraded image 2 address to system data flash section.

Sample code:

```
#include "flash_api.h"
#define WRITE_OAT_ADDR 1

flash_t flash;
//address:0x00080000
Uint32_t ota_addr = 0x00080000;
//boundary check
if((ota_addr > IMAGE_3) && ((ota_addr < (IMAGE_3+Img3Len))) ||
   (ota_addr < IMAGE_3) ||
   ((ota_addr & 0xffff) != 0) ||
   (ota_addr == ~0x0)){
    printf("\n\r[%s] illegal ota addr 0x%x", __FUNCTION__, ota_addr);
    goto update_ota_exit;
}else
    write_ota_addr_to_system_data( &flash, ota_addr);
```

## Read upgraded image 2 address from system data and verify this address

```
//Config in update.c
static void update_ota_local_task(void *param)
{
    ...
    //Get upgraded image 2 addr from offset
    flash_read_word(&flash, OFFSET_DATA, &NewImg2Addr);
    flash_read_word(&flash, IMAGE_2, &Img2Len);
    if((NewImg2Addr > IMAGE_3) && ((NewImg2Addr < (IMAGE_3+Img3Len))) ||
       (NewImg2Addr < IMAGE_3) ||
       ((NewImg2Addr & 0xffff) != 0) ||
       (NewImg2Addr == ~0x0))
        goto update_ota_exit;
```

---

The address of OFFSET\_DATA is 0x9000, and the address of upgraded image 2 is the first 4 byte from this address. If the address was not qualified, then the ota process will be stopped.

#### Define custom signature

```
//Config in update.c
1. turn on the marco as follows:
#define CONFIG_CUSTOM_SIGNATURE 1
2. Define your own signature.

#if CONFIG_CUSTOM_SIGNATURE
/* -----
 * Customized Signature
 * -----*/
// This signature can be used to verify the correctness of the image
// It will be located in fixed location in application image
#pragma location=".custom.validate.rodata"
const unsigned char cus_sig[32] = "Customer Signature-modelxxx";
#endif
3. compare it while complete flashing.
static void update_ota_local_task(void *param)
{
...
#if CONFIG_CUSTOM_SIGNATURE
    && !strcmp(read_custom_sig,custom_sig)
#endif
...
}
```

### 3.2.3 Local download server


Build new image New\_Project.bin in DownloadServer folder (path: tools\DownloadServer\).

 DownloadServer.exe	2014/6/13 ...	85 KB
 New_Project.bin	2014/8/13 ...	330 KB
 start.bat	2014/8/13 ...	1 KB

Edit start.bat file. Port = 8082, file = New\_Project.bin

```
1 @echo off
2 DownloadServer 8082 New_Project.bin
3 set /p DUMMY=Press Enter to Continue ...
```


Execute start.bat



```
C:\Windows\system32\cmd.exe
Listening on port <8082> to send New_Project.bin (337772 bytes)
Waiting for client ...
```


Reboot device and connect to AP.

Enter command: ATWO=IP[PORT].



```
# ATWO=192.168.1.100[1111]
[ATWO]: _AT_WLAN_OTA_UPDATE_
[MEM] After do cmd, available heap 25152
#
[update_ota_local_task] Update task start
[update_ota_local_task] Update OTA success!
[update_ota_local_task] Update task exit
```

Local download server success message:



C:\Windows\system32\cmd.exe

```
Listening on port <8082> to send New_Project.bin <337772 bytes>
Waiting for client ...
Accept client connection from 192.168.1.101
Sending .....
Total send 337772 bytes
Waiting for client ...
```

After finishing downloading image, device will be auto-rebooted, and the bootloader will load new image 2 if it exist.

### **3.3 OTA Signature**

To Clear or Recover OTA signature for verification via UART at command, please refer to AN0025.